



WINDSHIELD REPAIR KIT

Thank you for selecting this quality GRIOT'S product. Please read and follow these simple step-by-step instructions to achieve the best results. Should you have any questions about the **WINDSHIELD REPAIR KIT**, our Customer Service Department can be reached by phone at 800-345-5789 or by email at info@griotsgarage.com. Enjoy the best!



STEP 1



STEP 2



STEP 3



STEP 4



STEP 5



STEP 6

KIT INCLUDES

- Adhesive Pad
- Resin Chamber
- Resin Tube
- Syringe
- Razor Blade
- Curing Film

USEFUL INSTRUCTIONS

- Step 1: Clean and wipe dry the area surrounding the rock chip. Peel the brown paper off one side of the adhesive pad, exposing the adhesive. Attach the pad to the glass directly over the chip so you can see the damaged area through hole in the center of the pad.
- Step 2: Peel the green paper off the other side of the adhesive pad and attach the gray resin chamber, centered directly over the adhesive pad. Press firmly all around the base of the resin chamber to ensure that the adhesive is bonded to the glass and the base of the resin chamber. Cut the tip off of the resin tube, carefully insert into the top of the resin chamber, and squeeze 10 drops of the resin into the resin chamber.
- Step 3: With the syringe in the fully closed position, place the syringe into the resin chamber and hold firmly in place.
- Step 4: Slowly withdraw the top of the syringe so it is fully extended and hold for 2 minutes. This produces a vacuum to remove air from the crack. After the 2 minutes are complete, pull the plunger out of the syringe to end the vacuum.
- Step 5: Insert the plunger back into the syringe to just the beginning of the syringe tube. Then, while holding the base of the resin chamber down, slowly depress the plunger until you begin to feel resistance from the pressure that you are creating. Do not apply too much pressure or the adhesive pad may lose its seal. Hold syringe in this position for 5 minutes.
- Step 6: Remove the syringe, resin chamber and adhesive pad from the glass by slowly pulling on the tab at the top of the resin chamber. If necessary, use the razor blade to help loosen the bond of the adhesive to the glass. Add 1 to 2 drops of resin from the resin tube directly on the damaged area and place the curing film over the repaired area exposing to direct sunlight for 5 minutes. Note: This is very important. The UV rays from sunlight cure the resin. After waiting 5 minutes, remove the curing film and scrape off the excess resin using the razor blade. Keep the blade perpendicular to the glass and use a back and forth motion to remove excess resin. You can now clean the windshield and dispose of the used materials.

PRECAUTIONS AND DISCLAIMER

Always wear eye protection. Avoid resin contact with skin, eyes, and mouth. In case of eye contact, flush with water for 15 minutes and seek medical attention. GRIOT'S GARAGE is not responsible for any misuse of the **WINDSHIELD REPAIR KIT**, for any damage incurred to any person or object related to the Windshield Repair Kit.

ANSWERS TO YOUR QUESTIONS

Should you have any questions about the application of the **WINDSHIELD REPAIR KIT**, please call our Customer Service Department at 800-345-5789 or email to info@griotsgarage.com. For a complete selection of quality products or to receive a free GRIOT'S GARAGE handbook, please call us or visit us online at www.griotsgarage.com. Reorder item number 90201.

Have fun in your garage!®

GRIOT'S GARAGE, INC.
3333 SOUTH 38TH STREET
TACOMA, WA 98409
800-345-5789
www.griotsgarage.com

© GRIOT'S GARAGE, INC.