



# HEADLIGHT AND PROTECTIVE SHIELDS

Thank you for selecting this quality Griot's product. Our **PROTECTIVE SHIELDS** provide protection to painted surfaces, headlights and fog lights from expensive repair or replacement. Please read and understand all instructions before applying any protective film. Enjoy the best!

## SURFACE PREPARATION

Thoroughly clean the surface you are protecting to remove any wax or contaminants that may hinder adhesive from sticking to the surface. Dry with a lint-free cloth and make sure your hands are clean before applying. Before applying to surface, pre-cut film to an oversized piece approximately 1/2" larger size than the area you are protecting. Use scissors or a knife to cut while leaving the paper backing adhered to the film.

## APPLICATION OF FILM WITHOUT USING POSITIONING SPRAY AND SQUEEGEE

Peel off the paper backing from one side of the **PROTECTIVE SHIELD** (approximately 1 - 1 1/2"). Press the **PROTECTIVE SHIELD** to the paint or headlight starting at one edge. With moderate pressure, sweep the surface of the **PROTECTIVE SHIELD** across the lens surface. The **PROTECTIVE SHIELD** will adhere to lens. Work slowly as you pull back another 1 to 1 1/2" of paper until the lens has been fully covered. Press any remaining large air bubbles out to the edges of the lens. Smaller air bubbles will disappear over time. Trim your **PROTECTIVE SHIELD** by following the outer edge of your lens with a sharp knife being extremely cautious to not damage the paint or headlight. This can be achieved by using a disposable snap knife and setting the depth of the razor blade less than the thickness of the film.

## APPLICATION OF FILM USING POSITIONING SPRAY AND SQUEEGEE

Application is the same as above with the only difference being you pre-saturate the surface you are going to protect with the positioning spray. This will give you the ability to re-align the film should it not be centered and to remove bubbles with the squeegee. To remove air bubbles once the film is applied simply spray the film and use the squeegee to push the bubbles from the center of the film to the edges.

## PRECAUTIONS & DISCLAIMER

Do not wash the vehicle for 48 hours following application to allow the adhesive to set and fully cure. Installation is recommended in temperatures above 70° F (21° C). GRIOT'S GARAGE is not responsible for the misuse of the **PROTECTIVE SHIELD** or for any injury or damage incurred to any person or object related to the **PROTECTIVE SHIELD**. Not for use on repainted vehicle finishes.

## ANSWERS TO YOUR QUESTIONS

To order more **PROTECTIVE SHIELDS**, or for a complete selection of quality GRIOT'S GARAGE products, please write or call us toll-free at 800-345-5789. Or visit us at [www.griotsgarage.com](http://www.griotsgarage.com). Reorder item numbers: 77633 - 3/8" Wide, 77890 - 2" Wide, 77892 - 4" Wide, 10227 - 11"x17", 10228 - 22"x17" or 77896 Positioning Spray and Squeegee.

*Have fun in your garage!®*

GRIOT'S GARAGE, INC.  
3333 SOUTH 38<sup>TH</sup> STREET  
TACOMA, WA 98409

**800-345-5789**  
**[www.griotsgarage.com](http://www.griotsgarage.com)**

© GRIOT'S GARAGE, INC.