

Pivoting Blind-Spot Mirrors



For customer support please call
1-800-345-5789 or visit:
www.griotsgarage.com

© Griot's Garage, Inc.
3333 South 38th Street
Tacoma, WA 98409
(253) 922-2400



Pivoting Blind-Spot Mirrors, Set of 2

Installation Instructions

Item # 82044

Installation Instructions

1. The **Pivoting Blind-Spot Mirror** ball-and-socket is very tight from the factory and must be loosened before mounting. Simply rotate the base 4 to 5 times before installing.
2. Check window clearance by folding car mirrors all the way in before mounting your **Pivoting Blind-Spot Mirror**.
3. Thoroughly clean your car mirrors using rubbing alcohol only. No soaps or sprays of any kind. Then wipe with paper towel ONLY. (Don't allow alcohol to dry before wiping.)
4. Remove adhesive cover from the **Blind Spot Elimination Mirror**. (Do not touch the adhesive surface.)
5. Place the **Pivoting Blind-Spot Mirror** on both sideview mirrors as high and as close to the car as possible.
6. Lightly mount the **Pivoting Blind-Spot Mirror** to the desired spot. Then, push the car mirror all the way into the housing and apply light pressure to the **Pivoting Blind-Spot Mirror** for approximately 20 seconds.
7. Adjust the **Pivoting Blind-Spot Mirror** so you DO NOT see your own car.
8. Check and re-adjust after car wash.

NOTE: For drivers not experienced with the **Pivoting Blind-Spot Mirror**, it may take a couple weeks of driving and adjusting to become comfortable with your new mirrors. Initially, the mirrors may make things seem to appear too small, but this is a function of the mirror and allows you a wider side view. After a brief adjustment period you'll be comfortable using them.