



FOUR PEAK HORSEPOWER AIR BLOWER

Thank you for choosing this fine product from GRIOT'S GARAGE.

USEFUL INSTRUCTIONS

READ COMPLETELY BEFORE USING

1. Attach three-conductor extension cord to power supply. Insert male plug into electrical outlet
2. Fit the 10 ft. by 1 1/2" hose over the steel tube protruding from the front end cap of the power unit. The adjustable clamp will keep the hose on the dryer securely.
3. Start the blower by pushing the toggle switch from left to right.
4. The air velocity can be controlled by attaching or removing the neoprene nozzle or other attachments.

USE AS AN INFLATER

To use as an inflater select the small blower nozzle attachment. When inflating air mattresses, boats, rafts with large valves, place the nozzle into or against valve until inflatable is filled.

CAUTION

Do not drop this appliance. Motor malfunction caused by product being dropped is not covered under warranty.

DISCLAIMER

GRIOT'S GARAGE is not responsible for any misuse of the Four Peak Horsepower Air Blower for any injury or damage incurred to any person or object related to the Four Peak Horsepower Air Blower.

ANSWERS TO YOUR QUESTIONS

Should you want to order another Four Peak Horsepower Air Blower, or for a complete selection of quality GRIOT'S GARAGE products, please write, use the internet or call us toll-free at 800-345-5789. Reorder item number 15022.

Have fun in your garage!™

GRIOT'S GARAGE, INC.
3500-A 20th Street E.
Tacoma, WA 98424
800-345-5789
www.griotsgarage.com

© 2001 GRIOT'S GARAGE, INC.

