



## HEATED LUMBAR SUPPORT

Thank you for choosing this fine product from GRIOT'S GARAGE.

### USEFUL INFORMATION

The HEATED LUMBAR SUPPORT may be installed in your automobile, office, home or airplane - anywhere you need extra back support. A 12-volt outlet is required to operate the heat function.

1. Slip part A into part B as shown in the photo to the left..
2. Connect the front of part A to the two Velco® strips connected to the back of the HEATED LUMBAR SUPPORT.
3. Pull down the strap and connect it to the back of part A.
4. Take the completed HEATED LUMBAR SUPPORT support and press it firmly into the back of your seat. The back of plastic clip B should slide into the crease of the seat as shown in the photo at left.
5. The HEATED LUMBAR SUPPORT is now ready for use.

The hand pump inflates an internal air bag to give you just the right amount of pressure on your lumbar area. Simply squeeze the rubber bulb until the support feels comfortable. To deflate the HEATED LUMBAR SUPPORT, turn the bleeder valve on the side of the bulb and then retighten when the desired air pressure is achieved.

To turn on the heat function, plug the 12-volt adapter into your vehicle's 12-volt outlet. An internal thermostat automatically turns the unit on at temperatures at or below 93°F and off at 109°F.

### DISCLAIMER

GRIOT'S GARAGE is not responsible for any misuse of the HEATED LUMBAR SUPPORT for any injury or damage incurred to any person or object related to the HEATED LUMBAR SUPPORT.


### ANSWERS TO YOUR QUESTIONS

Should you want to order another HEATED LUMBAR SUPPORT, or for a complete selection of quality GRIOT'S GARAGE products please write, use the internet or call us toll-free. Reorder item number 77240.

*Have fun in your garage!™*

GRIOT'S GARAGE  
3500-A 20th Street E.  
Tacoma, WA 98424  
**800-345-5789**  
**www.griotsgarage.com**

© 2002 GRIOT'S GARAGE, INC



*Bracket is assembled by firmly snapping parts A and B together.*



*The correct position of brackets inserted into the seat. (Shown without Heated Lumbar Support attached.)*



*The fully assembled HEATED LUMBAR SUPPORT should look like this.*

