




BOSS™ G15 | G21

LONG-THROW ORBITAL POLISHER

Owner's Manual &
Safety Instructions



BRUSHLESS MOTOR
DIRECT-DRIVE
PRO-GRADE



WARNING: For your personal safety, READ and UNDERSTAND the instruction manual before using. **Questions:** Contact us at 800-345-5789



SAVE THESE INSTRUCTIONS

Models: 10675 | 10681

BOSS | BEST OF SHOW
SYSTEM®

TABLE OF CONTENTS

SAFETY WARNING & INSTRUCTIONS	3
DEFINITION OF SIGNAL WORDS	3
EXPLANATION OF SIGNAL WORD CONSEQUENCES	3
GENERAL POWER TOOL SAFETY WARNINGS	3
WORK AREA SAFETY	3
ELECTRICAL SAFETY	4
PERSONAL SAFETY	4
POWER TOOL USAGE AND CARE	4
POLISHER SAFETY WARNINGS	5
SAFETY WARNINGS COMMON FOR POLISHING OPERATIONS	5
SPECIFIC POLISHING SAFETY INSTRUCTIONS	5
KICKBACK AND RELATED WARNINGS	6
DUST AND CHEMICAL EXPOSURE WARNING	6
EXTENSION CORD USE	7
OPERATIONS	7
ACCESSORIES	7
INTENDED USE	7
TECHNICAL SPECIFICATIONS	8
FUNCTIONAL COMPONENTS	8
OPERATING INSTRUCTIONS	9
BACKING PLATE ASSEMBLY	9
POLISHING	10
PREVENTING SNAGGING	10
OPERATING THE POLISHER	10
PAD MAINTENANCE	11
TOOL MAINTENANCE	11
RECOMMENDED PADS, LIQUIDS, AND TOWELS	12
WARRANTY	13

SAFETY WARNING & INSTRUCTIONS

DEFINITION OF SIGNAL WORDS

The definitions below describe the level of severity for each signal word. Please read the manual and pay close attention to symbols.

-  **WARNING:** Description of hazard and possible resulting injuries or death.
-  **CAUTION:** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.
-  **NOTE:** Note emphasizes essential information.

EXPLANATION OF SIGNAL WORD CONSEQUENCES

	Read manual symbol	Alerts user to read manual and follow use instructions
	Wear eye protection symbol	Alerts user to wear eye protection
	Wear hearing protection symbol	Alerts user to wear hearing protection
	Wear Respiratory Protection	Alerts user to wear respiratory protection
	Do not discard symbol	Alerts user to proper disposal
	Class II Construction Symbol	Tool relies on double or reinforced insulation
	Arrow Symbol	Act in direction indicated by the arrow
	MET Symbol	This symbol designates that this tool is listed by the MET Laboratories, Inc., to United States and Canadian Standards.

GENERAL POWER TOOL SAFETY WARNINGS

-  **WARNING:** To reduce the risk of injury read safety warnings, instructions, illustrations, and specifications provided with this tool. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury. The term "power tool" in the warnings refers to your BOSS G15 and G21 Brushless Long-Throw Orbital Polisher.

WORK AREA SAFETY

1. Keep work area clean and well lit. Cluttered or dark areas invite accidents.
2. Do not operate power tool in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust. Power tools create sparks which may ignite the dust or fumes.
3. Keep children and bystanders away while operating power tool. Distractions can cause you to lose control.

ELECTRICAL SAFETY

1. Power tool's plug must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. Proper, unmodified plugs and matching outlets will reduce risk of electric shock.
2. Avoid body contact with earthed or grounded surfaces such as pipes, radiators, ranges, and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
3. Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
4. Do not abuse the cord. Never use the cord for carrying, pulling, or unplugging the power tool. Keep cord away from heat, oil, sharp edges, or moving parts. Damaged or entangled cords increase the risk of electric shock.
5. When operating power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric shock.
6. If operating power tool in a damp location is unavoidable, use a Ground Fault Circuit Interrupter (GFCI) protected power supply. Use of a GFCI reduces the risk of electric shock.

PERSONAL SAFETY

1. Stay alert, watch what you are doing, and use common sense when operating power tool. Do not use power tool while you are tired or under the influence of drugs, alcohol, or medication. A moment of inattention while operating power tool may result in serious personal injury.
2. Use personal protective equipment. Always wear eye protection. Use of protective equipment such as a dust mask, gloves, or hearing protection under appropriate conditions will reduce the chance of personal injury.
3. Prevent unintentional starting. Ensure the switch is in the "OFF" position before connecting to power source and/or battery pack, picking up, or carrying the tool. Carrying power tools with your finger on the switch or energizing power tools that have the switch "ON" invites accidents.
4. Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the tool may result in personal injury.
5. Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.
6. Dress properly. Do not wear loose clothing or jewelry. Keep hair, clothing, and gloves away from moving parts. Loose clothes, jewelry, or long hair can be caught in moving parts.
7. Do not let familiarity gained from frequent use of power tools allow you to become complacent and ignore tool safety principles. A careless action can cause severe injury within a fraction of a second.

POWER TOOL USAGE AND CARE

1. Do not force the power tool. Use the correct power tool for your application. The correct power tool will deliver optimal performance and is safer at the rate for which it was designed.
2. Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
3. Disconnect the power tool plug from the power source and/or battery pack before making any adjustments, changing accessories, or storing power tool. Such preventive safety measures reduce the risk of starting the power tool accidentally.
4. Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.
5. Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts, and any other condition that may affect power tool operation. If damaged, repair power tool before use. Many accidents are caused by poorly maintained power tools.
6. Use the power tool and accessories in accordance with these instructions, considering the working conditions and the task to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.
7. Keep handles and grasping surfaces dry, clean and free from polish, wax, oil, and grease. Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.

POLISHER SAFETY WARNINGS

SAFETY WARNINGS COMMON FOR POLISHING OPERATIONS

1. This power tool is intended to function as a polisher. Please read all safety warnings, instructions, illustrations and specifications provided with this power tool. Failure to follow all instructions listed herein may result in electric shock, fire, and/or serious injury.
2. Do not use this power tool to perform work such as roughing, fine sanding, brushing, or abrasive cutting. Operations for which the power tool was not designed may create a hazard and cause personal injury.
3. Do not convert this power tool to operate in a way which is not specifically designed and specified by the tool manufacturer. Such a conversion may result in a loss of control and cause serious personal injury.
4. Never use accessories that were not specially developed and designed for this power tool. Just because an accessory part can be fitted on your machine does not guarantee safe or optimum performance.
5. The rated speed of the accessory must be at least equal to the maximum speed communicated on the power tool. Accessories that rotate faster than the permissible level can break and fly apart.
6. The outside diameter and thickness of your backing plate must be within capacity rating of your power tool. Incorrectly sized accessories cannot be adequately guarded or controlled.
7. The dimensions of the accessory mounting must fit the dimensions of the mounting hardware of the power tool. Accessories that do not match the mounting hardware of the power tool will run out of balance, vibrate excessively and may cause loss of control.
8. Do not use a damaged accessory. Before each use inspect the accessory such as backing plate for cracks or tears. If power tool or accessory is dropped, inspect for damage or install an undamaged accessory. After inspecting and installing an accessory, position yourself and bystanders away from the plane of the rotating accessory and run the power tool at maximum no-load speed for one minute. Damaged accessories will normally break apart during this test time.
9. Wear personal protective equipment. Depending on application, use face shield, safety goggles, or safety glasses. As appropriate, wear dust mask, hearing protectors, gloves, and a workshop apron capable of stopping small abrasives or flying fragments. The eye protection must be capable of stopping flying debris generated by various operations. The dust mask or respirator must be capable of filtering particles generated by your operation. Prolonged exposure to high-intensity noise may cause hearing loss.
10. Keep bystanders a safe distance away from work area. Anyone entering the work area must wear personal protective equipment. Fragments of material or pieces of a broken accessory may fly away and cause injury beyond the area of operation.
11. Position the cord clear of the spinning accessory. If you lose control, the cord may be cut or snagged and your hand or arm may be pulled in causing injury.
12. Never lay the power tool down until the accessory has come to a complete stop. The spinning accessory may grab the surface and pull the power tool out of your control.
13. Do not run the power tool while carrying it at your side. Accidental contact with the spinning accessory may snag clothing, pulling the accessory into your body.
14. Regularly clean the power tool's air vents. The motor's fan will draw the dust inside the housing and excessive accumulation of powdered metal may cause electrical hazards or overheating.
15. Do not operate the power tool near flammable materials. Sparks could ignite these materials.
16. Do not use accessories that require liquid coolants. Using water or other liquid coolants may result in electrocution or shock.

SPECIFIC POLISHING SAFETY INSTRUCTIONS

1. Do not allow any loose portion of the polishing pad to spin freely. Tuck away or trim any loose attachment strings. Loose and spinning attachment strings can entangle your fingers or snag on the area being worked on.
2. Do not leave the tool running. Operate the tool only when hand-held.
3. If replacement of the power cord is necessary, replace with Griot's Garage Quick-Connect Power Cord: 10-Foot Item #10906 or 25-Foot Item #10905

KICKBACK AND RELATED WARNINGS

Kickback is a sudden reaction to a pinched or snagged rotating wheel, backing plate, brush, or any other accessory. Pinching or snagging causes rapid stalling of the rotating accessory which in turn causes the uncontrolled power tool to be forced in the direction opposite of the accessory's rotation at the point of the binding. For example, if a pad is snagged or pinched by the trim, the edge of the pad that is entering into the pinch point can dig into the surface of the material causing the wheel to climb out or kick out. The tool may either jump toward or away from the operator, depending on direction of the pad's movement at the point of pinching. Rotating accessories may also break under these conditions. Kickback is the result of tool misuse and/or incorrect operating procedures or conditions and can be avoided by taking proper precautions as given below.

1. Maintain a firm grip on the power tool and position your body and arm to allow you to resist kickback forces. The operator can control torque reaction or kickback forces, if proper precautions are taken.
2. Never place your hand near the rotating accessory. Accessory may kickback over your hand.
3. Do not position your body in the area where the power tool will move if kickback occurs. Kickback will propel the tool in direction opposite to the wheel's movement at the point of pinching.
4. Exercise extreme caution when working corners, sharp edges, etc. Avoid bouncing and snagging the rotating accessory. Corners, sharp edges, or bouncing have a tendency to snag the rotating accessory and cause loss of control or kickback.

DUST AND CHEMICAL EXPOSURE WARNINGS

 **WARNING:** Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm. Some examples of these chemicals are:

- Lead from lead-based paints.
- Crystalline silica from bricks, cement, and other masonry products.
- Arsenic and chromium from chemically-treated lumber.

Your risk from these exposures varies, depending upon how often you do this type of work. To reduce your exposure to these chemicals:

- Work in a well-ventilated area.
- Work with approved safety equipment, such as dust masks that are specially designed to filter out microscopic particles.
- Avoid prolonged contact with dust from power sanding, sawing, grinding, drilling, and other construction activities. Wear protective clothing and wash exposed areas with soap and water. Allowing dust to get into your mouth or eyes or to lie on the skin may promote absorption of harmful chemicals.

EXTENSION CORD USE

⚠ WARNING: AN EXTENSION CORD SHOULD NOT BE USED UNLESS ABSOLUTELY NECESSARY. If an extension cord is used, make sure:

- The plug pins match the product plug in number, size, and shape.
- The extension cord is properly wired and in good electrical condition.
- The wire gauge supports the product amp rating and cord length.
- An extension cord is a temporary solution. Move the product to a standard receptacle as soon as the job has been completed.

Use a cord with sufficient wire size. A smaller gauge number indicates a heavier cord with higher current capacity. An undersized cord causes voltage drop, power loss, and overheating. Refer to the table below for correct wire size. When in doubt, use the next heavier gauge. Do not connect multiple extension cords together.

Extension Cord Length	25' / 7.6m	50' / 15.24m	100' / 30.48m	150' / 45.7m
Cable Size (AWG)	16	16	16	14
Only use UL- and CSA-certified extension cords.				

OPERATIONS

⚠ CAUTION: Dispose of tool in accordance with local law. Recycle machines, accessories, and packaging at an environmentally responsible recycling center to reduce the risk associated with environmental contamination.

⚠ WARNING: To reduce the risk of serious personal injury, turn off power tool and unplug from power source before making any adjustments or removing/installing accessories or attachments.

⚠ CAUTION: Inspect polisher to ensure there are no damaged or missing parts prior to switching on.

ACCESSORIES

⚠ WARNING: To reduce the risk of injury, only Griot's Garage approved accessories should be used with this polisher. The Griot's Garage BOSS™ G15/G21 Brushless Long-Throw Orbital Polisher is designed for use with 5" or 6" Pad Systems. Use of any other size is not recommended.

INTENDED USE


The Griot's Garage BOSS G15 and G21 Brushless Long-Throw Orbital Polisher are designed for polishing paint, glass, unfinished metal, fiberglass, gelcoat, and composite surfaces. Common examples of use include but are not limited to auto, marine, RV, and motorcycle detailing.

TECHNICAL SPECIFICATIONS

TYPE	BOSS™ G15 (10675)	BOSS™ G21 (10681)
Orbit Size	15mm (.59")	21mm (.83")
Spindle Thread Size	5/16"- 24	
Orbits Per Minute (OPM)	3000 - 5300 (free speed)	3000 - 4800 (free speed)
Voltage	120V/60Hz	
Power Output (Watts)	500 Watts	
Power Output (Amperes)	5.5 amps	
Protection Class	II	
Cord Length	25' (7.6 meters) / 10' (3 meters) available for purchase	
Weight (Without Cord)	3.14 lbs /1.42 kg	3.24 lbs /1.47 kg
Constant Electronic Speed Control	Yes	
Progressive Variable Speed Trigger	Yes	
Factory Installed Backing Plate	5" (125mm)	6" (150mm)
Safety Restart Protection	Yes	
NOISE AND VIBRATION EMISSIONS		
TYPE	BOSS™ G15 (10675)	BOSS™ G21 (10681)
Vibration	2.9m/s²	3.8m/s²
Sound Pressure Level	65dB Uncertainty K=3 dB (A)	
Sound Power Level	82dB Uncertainty K=3 dB (A)	
ENVIRONMENTAL RECOMMENDATIONS		
TYPE	BOSS™ G15 (10675)	BOSS™ G21 (10681)
Recommended Ambient Operating Temperature	-4° – 104° F (-20° – 40° C)	

Vibration Emission Values Vibration total values ah (triax vector sum) and uncertainty K determined according to EN 62841-2-4

FUNCTIONAL COMPONENTS



- (A) Speed Control Dial
- (B) Variable Speed Trigger Throttle
- (C) Trigger Lock
- (D) Forward Grip
- (E) Ventilation Opening
- (F) Redline Indicator
- (G) BOSS Low-Pro Backing Plate
- (H) Quick-Connect Power Cord
- (I) Auxiliary Cooling Fan

OPERATING INSTRUCTIONS

-  **WARNING:** If any parts are damaged or missing, do not operate this product until the parts are replaced. Use of this product with damaged or missing parts could result in serious personal injury.
-  **WARNING:** A damaged power cord is a safety hazard! If the supplied cord or extension cord is damaged while work is in progress, immediately disconnect the device and the cord from the electricity supply. Do not touch the damaged part of the cord. Regularly check all supply cords. Replace defective cords.
-  **WARNING:** To prevent accidental starting that could cause serious personal injury, always remove the power cord from power outlet before assembling or adjusting parts.
-  **WARNING:** Always wear eye protection. Eye protection does not fit all operators in the same way. Make sure the eye protection chosen has side shields or provides protection from flying debris both from the front and sides.

Speed Control Dial (A)

The maximum speed of your polisher can be changed by rotating the Speed Control Dial (A). The polisher is equipped with a constant speed control so you can adjust the speed between "1" for the lowest and "6" for the highest. The Constant Speed Control circuitry will ensure consistent speed regardless of downward pressure or lack thereof. This feature delivers optimal performance, regardless of user technique and body panel shape.

Variable Speed Trigger Throttle (B)

Press the variable-speed trigger to turn the polisher on. The farther you pull the trigger, the faster the motor runs. Release the trigger to stop the motor. At full trigger pull, the machine operates at the speed set on the speed dial (A).

Trigger Lock (C)

Polisher can be locked on for continuous use by depressing the trigger and engaging the Trigger Lock Button (C) while releasing your finger from the trigger. To shut off, depress trigger and release.

-  **NOTE:** The polisher is equipped with Safety Restart Protection. Should polisher become unplugged during operation with trigger lock engaged, it will require trigger lock to be disengaged before normal operation will ensue.

Redline Indicator (F)

This polisher features redline indicators that signal performance limits. During normal operation, the opposing side panel LEDs illuminate white. If load or temperature exceeds safe operating levels, the LEDs turn red. Reduce applied pressure or allow the tool to cool until the lights return to white. Operating below redline helps protect internal components and extend service life.

-  **NOTE:** It is normal for the light bars to remain illuminated for approximately 80 seconds after the unit is switched off during the cool down cycle.

Quick-Connect Power Cord (H)

Your machine includes a 25-foot Quick Connect Power Cord. To install, align the Quick Connect plug with the power receptacle and push it in firmly until it clicks.

The click confirms a secure connection, and the machine is ready to operate. To remove the cord, press and hold the cord lock, then pull the cord straight out of the machine.

Auxiliary Cooling Fan (I)

When the tool is plugged in, the polisher's internal cooling fan will keep running for 80 seconds after the unit is switched off to help prevent overheating.

BACKING PLATE ASSEMBLY

-  **WARNING:** Always be sure that the tool is switched off and the power cord is disconnected from the power outlet before carrying out any work on the tool.
- 1. With tool resting on its back, align backing plate hub with tool output shaft.
- 2. Carefully line up the squared edge of the backing plate with the squared edge of the orbital shaft.
- 3. Insert Allen bolt and carefully thread into output shaft. Do not cross-thread!
- 4. Tighten bolt with supplied Allen wrench. With bolt bottomed out, securely tighten with a quarter turn. The power tool is configured with the backing plate mounted directly to the drive hub.
-  **CAUTION:** Ordinary maintenance: it's necessary to periodically check the correct tightening of bolt securing the backing plate using the supplied wrench.

POLISHING

 **WARNING:** To reduce the risk of injury, always wear proper eye protection marked to comply with ANSI Z87.1. When working in dusty situations, wear appropriate respiratory protection or use an OSHA-compliant dust-extraction solution.

Prior to application: It is recommended that all plastic and metal trim on vehicles be taped off using Professional Masking Tape for protection from incidental engagement with backing plate and/or pad.

Preventing Paint Burn-Through: Paint burn-through can happen quickly, particularly with microfiber or wool pads. Polishing at high speeds or holding the pad in one spot can damage the paint. Use light pressure, keep the polisher moving continuously, and use extra caution around edges and contour changes.

 **WARNING:** Avoid snagging on rough or sharp surfaces to reduce the possibility of "kickback".

PREVENTING SNAGGING

Snagging happens when a polishing pad catches on rough edges, causing the tool to kick back and potentially burn through paint. To minimize risk, use low speeds on rough surfaces. In tight or delicate areas, such as near trim or between mirrors and windows, avoid using a full-size polisher. Instead, polish by hand or use a mini polisher like our BOSS™ Hybrid Micro Polisher or G13 Mini Long-Throw Orbital Polisher.

 **CAUTION:** The backing plate and pad will continue to rotate briefly after the polisher is turned off.

Buffing Pads and Polisher Operation

Griot's Garage BOSS™ G15 and G21 Brushless Long-Throw Orbital Polishers are compatible with both BOSS Buffing Pads and Standard Griot's Garage Foam Pads. Proper pad selection, installation, and maintenance are essential for consistent results, safety, and vehicle finish integrity.

Pad Inspection and Installation

- Inspect the pad (microfiber, wool, or foam) before installation for wear, tearing, or deformation.
- Do not use torn or worn-out pads, as they can cause uneven polishing, swirl marks, or surface damage.
- Unplug the polisher before attaching or removing any pad.
- Attach the pad carefully: center it on the backing plate using the hook-and-loop system and press firmly around the pad. Off-center pads cause vibration.
- Never run the machine when the pad is not resting on the vehicle's surface.

OPERATING THE POLISHER

1. Select the least invasive method. (Chemical, Pad, Speed)
2. Apply Product
 - a. Spread product in a spiral motion from center outward.
 - b. Butter the pad face, working product into the pad using a domed cap.
3. Work Area
 - a. Focus on 2' x 2' sections.
 - b. Let panel contours guide your approach.
4. Operating Technique
 - a. Gradually press the trigger to minimize sling.
 - b. Spread product evenly, then increase speed according to instructions.
5. Correcting Defects
 - a. Follow polish or wax directions for optimal tool speed.
 - b. For correction, generally use speed 3 – 5 depending on defect severity.
 - c. Follow a grid pattern with light downward pressure.
 - d. Allow the pad to do the work; perform 3 – 4 passes, then wipe and evaluate.
6. Finishing
 - a. Wipe residue with a clean, dry microfiber towel.

PAD MAINTENANCE

1. While polishing, frequently clean the pad face using a Griot's Garage MOD™ Pad Conditioning Brush (speed 2). Frequent cleaning reduces product buildup, which can increase pad weight and vibration.
2. After polishing, remove the pad, pre-rinse with hot water, and wring to remove residue.
3. Spray Griot's Garage Microfiber & Foam Pad Cleaner on the pad face and gently knead to create a rich lather.
4. Rinse thoroughly with warm water and wring out, or machine wash if needed.
5. Allow the pad to dry completely before use and store in the supplied packaging.

Pad Management Best Practices

- a. Use 3–4 pads or more per process to maintain smooth operation, consistent results, and pad longevity.
- b. Replace pads regularly, even with proper cleaning, to ensure optimal performance and protect vehicle finishes.
- c. Match pad type and size to the polishing application.
- d. Avoid excessive pressure; let the pad and polish do the work.
- e. Store pads in a clean, dry area to preserve condition.

Backing Plate Care

 **CAUTION:** Frequently inspect the backing plate for polish residue.

NOTE: Buffing pads can become saturated, allowing residue to transfer onto the backing plate hook. This can reduce pad adhesion and increase the risk of pad fly-off. If the plate becomes contaminated:

1. Remove it from the machine.
2. Apply Griot's Garage Microfiber & Foam Pad Cleaner, allow it to dwell, then agitate with a stiff nylon brush.
3. Rinse thoroughly and allow to air dry completely before reinstalling.

TOOL MAINTENANCE

For detailed product use, please visit griotsgarage.com for tech sheets and helpful how-to videos. Your Griot's Garage BOSS G15/G21 Brushless Long-Throw Orbital Polisher has been designed to operate over a long period of time with minimum maintenance. To maintain optimal performance and long-life, proper tool care and regular cleaning must be employed.

 **WARNING:** To reduce the risk of serious personal injury, turn off power tool and unplug from power source before making any adjustments or removing/installing accessories or attachments.

 **WARNING:** Wear proper ANSI Z87.1 (CAN/CSA Z94.3) eye protection and proper NIOSH/OSHA/MSHA respiratory protection when cleaning tools with compressed air.

 **NOTE: Blow dirt and dust out of all ventilation openings (E) with dry compressed air at least weekly under daily use.** Ventilation openings and switch levers must be kept clean and free of foreign matter. Do not attempt to clean by inserting pointed objects through openings.

 **CAUTION:** Never use solvents or other harsh chemicals for cleaning the non-metallic parts of the tool. These chemicals will attack and weaken the nylon composite materials used in these parts. Griot's Garage Citrus Multi-Surface Cleaner is a safe and effective option. Apply liberally, agitate with a soft nylon bristle brush, then wipe tool down with a damp, microfiber towel.

 **CAUTION:** When servicing, use only identical replacement parts. Use of any other parts could create a hazard or cause product damage. Periodically inspect the entire product for damaged, missing, or loose parts such as screws, nuts, bolts, caps, etc. Tighten securely all fasteners and caps and do not operate this product until all missing or damaged parts are replaced. Please contact customer service or an authorized service center for assistance.

STORAGE Store the tool indoors in a place that is inaccessible to children. Keep away from corrosive agents.

FAILURE TO START

1. Should your tool fail to start, check to make sure the prongs on the cord plug are making good contact within the outlet. Also check for blown fuses or open circuit breakers in the line.
2. Inspect power cord for cuts or shorts. Remove Quick Connect Power Cord (H), then reinsert ensuring "click" sound is audible. Should excessive wear be identified, contact Griot's Garage for replacement cords and/or service

RECOMMENDED PADS, LIQUIDS, AND TOWELS

STANDARD PADS



Orange Foam Correcting Pad
This dense, firm foam pad can be used for removal of light to moderate defects.



Black Foam Finishing Pad
This soft, multi-purpose foam pad removes light scratches and mild defects.



Red Foam Waxing Pad
This ultra-soft pad delivers vibrant color and durable paint protection.



Glass Polishing Pad
Power away water spots and road grime to create crystal clear clarity. (6" only)

5 INCH

6 INCH

BOSS PADS



BOSS™ Knitted Wool Pad
Accelerate the cut rate of any polish to rapidly remove the most severe defects.



BOSS™ Microfiber Pad
This aggressive pad provides rapid removal of moderate to severe defects.



BOSS™ Microfiber Fast Cutting Pad
Engineered for maximum cutting power, this pad tackles the most severe paint defects.



BOSS™ Fast Correcting Foam Pad
Our most aggressive foam pad, this ultra-firm pad removes moderate to severe defects.



BOSS™ Correcting Foam Pad
This workhorse of a pad eliminates light to moderate scratches and defects.



BOSS™ Perfecting Foam Pad
This multi-purpose pad removes light swirl marks, micro hazing, and water spots.



BOSS™ Finishing Foam Pad
This ultra-soft pad delivers optimal color, depth, and clarity on delicate finishes.

5 INCH

6 INCH

BOSS | BEST OF SHOW SYSTEM

BOSS LIQUIDS



BOSS™ Fast Correcting Cream
Quickly removes severe defects while adding depth and clarity to your paint.



BOSS™ Correcting Cream
Eliminate moderate defects like light scratches and swirl marks while adding depth and clarity.



BOSS™ Perfecting Cream
A two-for-one, that removes light imperfections and creates rich, deep, durable protection.



BOSS™ Finishing Sealant
All-in-one that eliminates fine swirls, scratches, and hazing while producing a flawless finish.



BOSS™ Ceramic All-In-One Wax
Multifunctional formula combines maximum polishing power with ceramic protection for a strong high-gloss finish!

BOSS | BEST OF SHOW SYSTEM

TOWELS



Microfiber Edgeless Towels
This versatile towel quickly removes polish, wax, spray detailers, and more.



Microfiber Plush Edgeless Towels
Ensure nothing but supple, plush-nap microfiber touches your paint.



PFM™ Dual Weave Wax Removal Towels
Remove wax and buff in a safe, efficient manner.



PFM™ Terry Weave Towels
An all-around towel that excels at drying, wax/polish wipe downs, & more.

WARRANTY

PRODUCT USE

All statements, usage recommendations, and technical information contained in this manual are based on tests or development that Griot's Garage has deemed reliable. However, many factors beyond Griot's Garage's control can affect the use and performance of this Griot's Garage product in a certain application, including conditions under which the Griot's Garage product is used and the time and environmental conditions in which the product is expected to perform. Since these factors are uniquely in the user's knowledge and control, it is the responsibility of the user to evaluate the Griot's Garage product to determine whether it is suitable for a particular purpose and the user's method of application.

WARRANTY

Griot's Garage Lifetime Guarantee Griot's Garage will repair or replace any defective tool, without charge, due to faulty materials or workmanship for the working life of the tool, subject to certain exclusions below.

SIX MONTH SATISFACTION GUARANTEE

We want you to enjoy our quality product and have fun with it! If you're not 100% satisfied for any reason within six months of purchase, return it to point of sale with proof of purchase for a full refund or credit.

EXCLUSIONS

Griot's Garage Lifetime Guarantee does not cover damage caused by failure to follow recommended maintenance, misuse, alteration, or abuse. Normal wear and tear are not considered a defect, therefore part failure which may occur as the result of ordinary use is excluded from coverage.

DISCLAIMER

Limitation of Liability. In no event shall the monetary liability of company exceed amounts that have actually been paid to company. Company shall not be liable for consequential, indirect, special, or incidental damages under any circumstances, even if advised in advance of the possibility of such damages.

ANSWERS TO YOUR QUESTIONS

To order additional pads and liquids, or for a complete selection of Griot's Garage products, please call us toll-free at **800-345-5789**, email us at **customerservice@griotsgarage.com**, or go to **griotsgarage.com**.

This image shows a blank sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.



Have fun in your garage!®