

FOUR-PEAK HORSEPOWER AIR BLOWER

Thank you for selecting this quality Griot's product. The **Four-Peak Horsepower Air Blower** is designed to help you remove water from hard-to-dry areas with a powerful stream of air. Enjoy the best!

USEFUL INSTRUCTIONS

- 1. Attach three-conductor extension cord to power supply. Insert male plug into electrical outlet.
- 2. Fit the 10 ft. by $1\frac{1}{2}$ " hose over the steel tube protruding from the front end cap of the power unit. The adjustable clamp will keep the hose on the blower.
- 3. Start the blower by pushing the toggle switch from left to right.
- 4. The air velocity can be controlled by attaching or removing the neoprene nozzle or other attachments.

To use as an inflater, select the small blower nozzle attachment. When inflating air mattresses, boats, rafts with large valves, place the nozzle into or against valve until inflatable is filled.

DISCLAIMER

GRIOT'S GARAGE is not responsible for any misuse of the **Four-Peak Horsepower Air Blower** for any injury or damage incurred to any person or object related to the **Four-Peak Horsepower Air Blower**.

ANSWERS TO YOUR QUESTIONS

Should you have any questions about the **Four-Peak Horsepower Air Blower**, please call our Customer Service Department at 800-345-5789 or email to info@griotsgarage.com. For a complete selection of quality products or to receive a free Griot's Garage handbook, call us or visit online at www.griotsgarage.com. Reorder item number 15022.

Have fun in your garage!®

Griot's Garage, Inc. 3333 South 38th Street Tacoma, WA 98409 **800-345-5789** www.griotsgarage.com

© GRIOT'S GARAGE, INC.