

BRILLIANT FINISH FOAMING SPRAYER

Our Brilliant Finish Foaming Sprayer is powered by a water hose and covers your vehicle in a rich layer of lubricating suds. The suds will help loosen, encapsulate, and lift dirt away from the vehicle's surface. The Foaming Sprayer is a great option to clean SUVs, RVs, boats, and more. The 32-ounce reservoir holds enough wash to effectively clean small to large vehicles. The quick-connect trigger nozzle provides a strong spray to power away dirt and grime, while easily connecting to the Foaming Sprayer for more suds. Foaming Sprayer works well with various washes we offer including Brilliant Finish Car Wash, Brilliant Finish Snow Foam, Best of Show® Wash & Wax, Ceramic Wash & Coat or BOSS™ Foaming liquids.

Directions: Make sure all surfaces are out of direct sunlight and cool to the touch.

- **1.** Fill container with 32 oz of water, then add the appropriate amount of your favorite Griot's Garage car wash from the instructions on its label.
- **2.** Screw on the container to the hi-flow foam gun and attach the pistol grip nozzle to the sprayer using the quick-connect feature. You'll hear a click when engaged.
- **3.** Grip and squeeze the nozzle handle and add foam to all your vehicle surfaces. For best results foam from the bottom up.
- **4.** Once the surface is covered, use your wash mitt/pad to agitate the surface from the top down. For best results use a bucket with soapy water to rinse your wash mitt/pad regularly.
- **5.** When washing is complete, disconnect the nozzle from the foam gun, rinse the surface free of suds, and dry.

For use with Synthetic Clay or other surface prep tools: Make sure all surfaces are out of direct sunlight and cool to the touch.

- 1. Wash car as instructed above without the drying step.
- **2.** While the car is still wet after rinsing, apply foam to the surface as well as directly to the surface prep tool. Ceramic Wash & Coat should not be used for this step. All other car wash products listed above are safe to use.
- **3.** Glide the tool you are using over all smooth, hard surfaces (including glass) in overlapping passes with gentle pressure.
- 4. Reapply soap if tool begins to stick.
- **5.** When claying is complete, disconnect the nozzle from the foam gun and rinse the surface free of suds and dry.

Maintenance: After use, wash, rinse, and air dry all parts to ensure long working life. Should pistol grip nozzle trigger become slow to turn off, add drop of oil or lubricant to brass nozzle shaft. Disconnect from water source, squeeze handle, and add lubricant. Allow lubricant to work through the system by squeezing and releasing nozzle several times.

WARNINGS:

- · Screw lid firmly onto container until tight.
- · Always use protective clothing and eyewear when dispensing chemicals or other materials.
- · Observe safe handling instructions of chemical manufactures.
- The spray gun and quick connector must be firmly attached to the lid.
- · Maximum water pressure 85 psi.
- · Tap water outlets only.

