



FOLDING POP-UP CART

Thank you for choosing this fine product from GRIOT'S GARAGE. The FOLDING POP-UP CART is easy to assemble and convenient to use. Enjoy the best.

USEFUL INFORMATION

The following instructions have been prepared to help you assemble the FOLDING POP-UP CART. If you encounter any problems please give us a call at 1-800-345-5789.

ASSEMBLY INSTRUCTIONS

1. Remove the parts from the box and make sure everything is there.

The hardware bag should contain the following:

- 1-machine screw
- 1-nyloc nut
- 2-axle washers
- 2-pal nuts (looks like a hat)
- 1-rubber handgrip

You should also have the following parts:

- 1-axle shaft
- 1-cart chassis
- 1-folding crate (may be attached to the chassis)
- 2-tires
- 1-lower handle (attached to the bottom of the chassis).
- 1-middle handle (with release button installed on bottom end)
- 1-upper handle



Figure 1 - Pal nut and washer assembly.




Figure 2 - axle assembly.



Figure 3 - handle assembly.



Figure 4 - lower handle assembly.

2. Attach one of the pal nuts (looks like a hat) to the axle by placing the pal nut on a hard surface and tapping the axle with a soft mallet. Next slide one washer down against the pal nut then slide on one wheel with the solid side against the washer. (Figure 1)

3. Slide the axle assembly through the holes in the chassis and lower handle. The lower handle should already be installed in the chassis. If the holes in the lower handle do not line up then twist the handle to align the hole until the axle slides through. (Figure 2)

4. Slide the second wheel onto the axle with the hollow side against the chassis and place the second washer onto the axle. **EXTREMELY IMPORTANT!** Before tapping the second pal nut onto the axle, make sure everything is properly installed. Once the pal nut is installed it is difficult to remove and cannot be reused. If everything is installed correctly, tap the second pal nut onto the axle.

5. Slide the upper handle onto the middle handle, lining up the holes. Install and tighten the machine screw and nyloc nut. Slide the handgrip onto the end of the upper handle. You may dampen the inside of the rubber handgrip with soapy water. This will help it slide onto the upper handle. (Figure 3)

6. Insert the handle assembly into the lower handle. Depress the release button located in the bottom of the handle assembly. This will allow the two handles to connect and lock together. Make sure the release button is aligned with the hole in the lower handle. To remove the handle assembly, depress the release button and pull out on the handle. A slight jiggle will make it easier to remove. (Figure 4)

7. Lift the crate by its top rail to open. The end panels should fall down but may need assistance. Tap lightly on the lower half of the end panels to make sure they snap into place. To close the crate, push lightly in on the lower half of the end panels and bring them up to the top rail. Fold the sides of the crate towards the center to collapse it flat. (Figure 5)



Figure 5 - Opening the crate.



Figure 6 - Clip crate onto cart.

8. To install the crate onto the chassis hook one bottom end lip of the basket (either end) under the front lip of the chassis (nearest the handle). You should always clip the front end first. Once the front end is secured, push the crate straight down and it should snap into the clip at the rear of the chassis. To remove the crate, pull out on the rear clip and lift the back of the crate straight up. (Figure 6)

WARNING

The FOLDING POP-UP CART is not intended to carry people, children or pets. Caution should be exercised when using the FOLDING POP-UP CART on sloped driveways, hills or near any incline. Caution should also be taken to place any load in the center of the cart and distribute the weight evenly from the center to the outside edges.

DISCLAIMER

GRIOT'S GARAGE is not responsible for any misuse of the FOLDING POP-UP CART, for any injury or damage incurred to any person or object related to the FOLDING POP-UP CART.

ANSWERS TO YOUR QUESTIONS

Should you want to order another FOLDING POP-UP CART, or for a complete selection of quality GRIOT'S GARAGE products, please write or call us toll-free at 800-345-5789. You can use the internet at www.griotsgarage.com. Reorder item number 71978.

*Have fun in your garage!**

GRIOT'S GARAGE, INC.
3333 SOUTH 38TH STREET
TACOMA, WA 98409
800-345-5789
www.griotsgarage.com

© GRIOT'S GARAGE, INC.